# PROJECT CENTER

http://www.cricut.com

## VINYL SOUTHWEST KITCHEN

**Design by:** CricutAddictForever (1 Project)
**About me:** I am a mother a two wonderful children and love working on papercrafts and scrapbooking. I love to make things and give them away.
**Project skill level:** advanced
**Project time:** 2 hours to 3 hours
**Project tags:** Home Décor/Accents Photos/Frames/Boards Wall Décor/Wreaths/Banners Outdoors Outdoor/Animal Layouts Vacation/Travel Layouts Outdoor Recreation Southwest

Vinyl - Southwest Theme on my Kitchen Cabnets. I wanted to give my cabnets a touch of the southwest flair and bring out the Native American Heritage that lives in the house.

## CRICUT ®: WHAT WAS USED

Cricut Expression® 2

Cricut® Everyday Cartridge, Southwest

## OTHER MATERIALS NEEDED

- Masking Tape
- Vinyl
- scissors

## STEP 1

I cut the bottom solid border layer in red vinyl at 7 1/2" X2 1/2" and the corners at 2 1/2" X2 1/2". Then I selected turquoise vinyl for the top layer and cut them at 7 1/2" 2 1/2" and the corners at 2 1/2" X2 1/2". I also cut the bird for the corners in yellow vinyl at 3/4". First I cut all the base, then the middle then the top. Cut vinyl at pressure 3, blade 3, multi cut 1, and speed for this cartridge at 2 - it will give it a "kiss" cut which cuts only the vinyl and leaves the backing. Layering more than 2 can be a little more difficult but it's very easy to do.

## STEP 2

Once cut - I start w/ the bottom layer and "weed" out all the negative space - a good pair of tweezers works great for this. I then weed the middle layer, and then the top.

## STEP 3

I take the middle layer and lay it on top of the bottom. (I work this way as I find it works better) then I take the top and layer on the middle. Layering 2 is pretty easy but layering 3 is a little harder as you have 2 other layers to work with. However I only have three layers on the corners.

## STEP 4

To transfer the finished borders and corners I use transfer tape (masking tape works great also). I lay the length of transfer tape over the words and rub. Lift off the transfer tape SLOWLY - then place on the kitchen cabnets.

## RELATED PROJECTS

Princess Box

View details

Word Collage Boards

View details

Journey Wall

View details

http://www.cricut.com